TIROSS®

TS1375



INSTRUCTION MANUAL
STAND BLENDER 2

INSTRUKCJA OBSŁUGI
BLENDER KIELICHOWY 6

Instruction Manual
STAND BLENDER TS1375

GB

Dear Customer,
Welcome to use TIROSS stand blender.
Please read this instruction carefully before use.

■ PARTS DESCRIPTION

1. Lid with feeding shaft
2. Glass can
3. Blades
4. Speed button
5. Base



■ SAFETY

- By ignoring the safety instructions the manufacturer can not be hold responsible for the damage.
- If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.
- Never move the appliance by pulling the cord and make sure the cord can not become entangled.
- The appliance must be placed on a stable, level surface.
- The user must not leave the device unattended while it is connected to the supply.
- This appliance is only to be used for household purposes and only for the purpose it is made for.
- This appliance shall not be used by children from 0 year to 8 years. This appliance can be used by children aged from 8 years and above if they are continuously supervised. This appliance can be used by people with reduced physical, sensory or mental capabili ties or lack of experience and knowledge if they have been given supervision or instruc tion concerning use of the appliance in a safe way and understand the hazards involved. Keep the appliance and its cord out of reach of children aged less than 8 years. Cleaning and user maintenance shall not be made by children.
- To protect yourself against an electric shock, do not immerse the cord, plug or appliance in the water or any other liquid.
- Do not allow children to use the device without supervision.
- Switch o the appliance and disconnect from supply before changing accessories or approaching parts that move in use.
- Always disconnect the device from the supply if it is left unattended and before assem bling, disassembling or cleaning.
- It is absolutely necessary to keep this appliance clean at all times, because it comes into direct contact with food.
- **NOTE:** The chopping blades are very sharp, avoid physical contact during emptying and cleaning the device, you can seriously injure.
- This appliance is intended to be used in household and similar applications such as:

– Sta kitchen areas in shops, o ces and other working environments.
– By clients in hotels, motels and other residential type environments.
– Bed and breakfast type environments.
– Farm houses.

■ BEFORE THE FIRST USE

- Take the appliance and accessories out the box. Remove the stickers, protective foil or plastic from the device.
- Place the device on a flat stable surface and ensure a minimum of 10 cm. free space around the device. This device is not suitable for installation in a cabinet or for outside use.
- Before using your appliance for the first time, wipe o all removable parts with a damp cloth. Never use abrasive products.
- Put the power cable into the socket. (Note: Make sure the voltage which is indicated on the device matches the local voltage before connecting the device. Voltage 220V-240V 50/60Hz 500W)
- **Caution!** Run the blender no longer than 1 minute continuous, after that always cool the blender for 1 minute.

USE

- Place the base on a flat stable surface, not near a sink filled with water or a similar setting. Make sure the appliance is not connected to the main supply and the speed selector is in the ‘o ’ position.
- Select ‘1’ for the slow modus , select ‘2’ for a faster mode, select 0 to turn o the appli ance. For a short and fast operation, select the Pulse mode, you need to hold down the switch in this position, not longer than 1 minute, due to possible overheating of the engine. Allow the unit to cool down before further use.

CLEANING AND MAINTENANCE

- Always remove the plug from the socket when the device will be cleaned.
- Clean the appliance with a damp cloth. Never use harsh and abrasive cleaners, scouring pad or steel wool, which damages the device.
- Never immerse the electrical device in water or any other liquid. The device is not dishwasher proof.
- Components that have come into contact with food can be cleaned in soapy water.
- The components are not suitable for cleaning in a dishwasher. If exposed to heat or caustic cleaners they might become misshapen or discoloured.

⚠ GUIDELINES FOR PROTECTION OF THE ENVIRONMENT

This appliance should not be put into the domestic garbage at the end of its durability, but must be o ered at a central point for the recycling of electric and electronic domestic appliances. This symbol on the appliance, instruction manual and packaging puts your attention to this important issue. The materi-als used in this appliance can be recycled. By recycling of used domestic appliances you contribute an important push to the protection of our environment. Ask your local authorities for information regarding the point of recollection.

INFORMATION

This symbol on our product nameplates proves its compatibility with the EU Directive 2002/96 concern-ing proper disposal of waste electric and electronic equipment (WEEE). This symbol indicates that this product must not be disposed of with your other waste. You must hand it over to a designated collection point for the recycling of electrical and electronic equipment waste. The disposal of the product should obey all the speci c Community waste management legislation’s. Contact your local city of ce, your waste disposal service or the place of purchase for more information on the collection.

Instrukcja obsługi
BLENDER TS1375

PL

Drogi Kliencie,
dziękujemy za zakup wysokiej jakości blendera TIROSS.
Aby długo i z satysfakcją go używać, prosimy o dokładne zapoznanie się z niniejszą instrukcją obsługi.

■ OPIS WYPOSAŻENIA

1. Pokrywa z podajnikiem
2. Naczynie szklane
3. Ostrza
4. Regulator prędkości
5. Podstawa



■ BEZPIECZEŃSTWO

- W przypadku ignorowania zaleceń dotyczących bezpieczeństwa producent nie ponosi odpowiedzialności za uszkodzenia urządzenia.
- Jeżeli przewód zasilający jest uszkodzony, powinien być wymieniony przez producenta, jego punkt serwisowy lub wykwalifikowany personel. Ignorowanie tego zalecenia może spowodować zagrożenie.
- Nie wolno przesuwać urządzenia, ciągnąc za przewód zasilający. Należy upewnić się, że przewód nie jest zaplątany.
- Urządzenie należy umieścić na stabilnej, poziomej powierzchni.
- Nie wolno pozostawiać bez nadzoru miksera podłączonego do zasilania. Urządzenie jest przeznaczone do użytku w gospodarstwie domowym do celów przewidzianych przez producenta.

- Urządzenie nie powinno być używane przez dzieci w wielu 0–8 lat. Urządzenie może być używane przez dzieci w wieku powyżej 8 lat pod warunkiem, że są one pod nieustan nym nadzorem. Urządzenie może być używane przez osoby o ograniczonej sprawności fizycznej, sensorycznej lub umysłowej albo niedostatecznym doświadczeniu lub wiedzy pod warunkiem, że są one nadzorowane lub zostały przeszkolone w zakresie bezpiecz nego korzystania z urządzenia i poinformowane o związanych z tym zagrożeniach. Należy przechowywać urządzenie i przewód zasilający w miejscu niedostępnym dla dzieci w wieku poniżej 8 lat. Prace związane z czyszczeniem i konserwacją urządzenia nie powinny być wykonywane przez dzieci.
- Nie wolno zanurzać przewodu, wtyczki ani urządzenia w wodzie lub innej cieczy, ponieważ może to spowodować porażenie prądem elektrycznym.
- Nie wolno zezwalać dzieciom na korzystanie z urządzenia bez nadzoru.
- Przed wymianą akcesoriów lub serwisem ruchomych podzespołów należy wyłączyć urządzenie i odłączyć zasilanie.
- Należy zawsze odłączać zasilanie urządzenia, jeżeli zostanie pozostawione bez nadzoru, oraz przed montażem, demontażem lub czyszczeniem.
- Należy zawsze czyścić urządzenie, ponieważ styka się ono z produktami spożywczymi.
- **UWAGA:** Należy zachować ostrożność podczas opróżniania i czyszczenia urządzenia, aby zapobiec poważnemu zranieniu przez ostrza tnące.
- Urządzenie jest przeznaczone do użytku w gospodarstwie domowym i podobnych lokalizacjach:

– pomieszczenia kuchenne dla personelu w sklepach, biurach oraz innych miejscach pracy,
– pokoje w hotelach, motelach i innych budynkach mieszkalnych,
– kwatery prywatne,
– budynki mieszkalne na farmach.

■ PRZED UŻYCIEM URZĄDZENIA PO RAZ PIERWSZY

- Wyjmij urządzenie i akcesoria z opakowania. Usuń naklejki, folię zabezpieczającą i zabezpieczenia z tworzywa sztucznego z urządzenia.
- Umieść urządzenie na płaskiej, stabilnej powierzchni, zachowując odstęp co najmniej 10 cm wokół urządzenia. Urządzenie nie jest przystosowane do montażu w szafce lub użytku poza budynkami.
- Przed użyciem urządzenia po raz pierwszy przetrzyj wszystkie odłączane elementy wilgotną ściereczką. Nie wolno używać substancji ściernych.
- Podłącz przewód zasilający do gniazda sieci elektrycznej. (Uwaga: Przed podłączeniem zasilania urządzenia należy upewnić się, że napięcie podane na tabliczce znamionowej jest zgodne z napięciem sieci elektrycznej. Napięcie 220–240 V, 50/60 Hz, 500 W.)
- **Przestroga!** Należy uruchomić urządzenie na czas nie dłuższy niż jedna minuta w trybie ciągłym, a następnie zawsze poczekać na ochłodzeni urządzenia przez jedną minutę.

KORZYSTANIE Z URZĄDZENIA

- Umieść podstawę na płaskiej, stabilnej powierzchni, z dala od zlewu napełnionego wodą lub podobnej lokalizacji.
  Upewnij się, że urządzenie nie jest podłączone do zasilania, a przełącznik prędkości jest ustawiony w położeniu „0".
- Wybierz ustawienie „1" (mała prędkość), ustawienie „2" (duża prędkość) lub ustawienie „0", aby wyłączyć urządzenie. Aby uruchomić urządzenie z dużą prędkością, wybierz tryb pulsacyjny, naciskając i przytrzymując przełącznik w danym położeniu przez maksymalnie jedną minutę. Dłuższe uruchomienie może spowodować przegrzanie silnika. Przed ponownym uruchomieniem poczekaj na ochłodzenie urządzenia

CZYSZCZENIE I KONSERWACJA

- Zawsze przed czyszczeniem urządzenia wyjmij wtyczkę przewodu zasilającego z gniazda sieci elektrycznej.
- Oczyść obudowę wilgotną ściereczką. Nie używaj szorstkich lub ściernych środków do czyszczenia, materiałów do szorowania ani wełny stalowej, ponieważ może to spowodować uszkodzenie urządzenia.
- Nie zanurzaj urządzenia elektrycznego w wodzie lub innej cieczy. Urządzenie nie jest przystosowane do mycia w zmywarce do naczyń.
- Elementy stykające się z produktami spożywczymi można czyścić płynem do mycia naczyń.
- Elementy urządzenia nie są przystosowane do mycia w zmywarce do naczyń.
  nna eważ może
  o en zi o