TIROSS®

TS1303



INSTRUCTION MANUAL
ELECTRONIC
KITCHEN SCALE

2

INSTRUKCJA OBSŁUGI
ELEKTRONICZNA
WAGA KUCHENNA

8


CE RoHS compliant EAC






■ ZERO or TARE FUNCTION

To weigh different loads conse ly without removing loads form scale. Put first Load on the scale, get weight Press **ZERO** button LCD reading to '0" before adding next load. Y at this



ads on the scale
(4% = 80g when
is 5000g)

ent. 0g and mean-
ains unchanged.



4% of scale's
capacity is

is pressed. -----
ent. 0g and mean-
D mean TARE
y is reduced by

ight of all loads
oads, just press