
INSTRUCTION USE **TS**2902

Thank you fo
wine opener


BE RE FIRS

To ure safe
qu of
yo d a fo
ca ly.
D t im erse the
o ot liquid to a
j age to the pro
K arts (e.g. hands)
a e corkscrew to avo
K oduct away from chil
D antle the product by you
ot e warranty will be invalid.
D the product onto a bottle.
D his product for any other
pu
K rom flammable, explosive
ga

PRO SCRIPTION



1. Handle
2. Screw
3. Foil cutter



Take the foil cutter off and put onto the bottleneck, hold with fingers by force, rotate the bottle in parallel for more than one circle, and cut off the foilseal



Place the bottom of corkscrew body on top of the wine bottle, hold the bottle firmly with one hand and then spin the handle clockwise with the other hand.



f the body of the cork-
with one hand, and then
andle anti-clockwise
r hand until
out from the

- This p m
  a diame
  and a heig
- This product
  with an bottlene
  more than 35 mm
  diameter of between

- Hold the product body and the w
  bottle firmly during use.
- The blade of foil cutter is sharp.
  Don't touch with fingers.
- Please store this product out of reach
  from children.
- Align the product body with the wine bottle
  as much as possible, or otherwise the
  cork cannot be pulled out easily.

www.tiross.com